

EZ-Tint

INSTALLATION TOOL FROM



STEALTH FILM INSTALLATION INSTRUCTIONS:

1. Wet the EZ-Tint Tool insertion panel with slip solution.
2. Apply XPEL STEALTH film on the bottom of the EZ-Tint tool insertion panel, wrapping it around the leading edge.



3. Work out bubbles & moisture, letting film dry properly before using the EZ-Tint tool.

PLEASE INSTALL PROTECTIVE FILM BEFORE USING THE EZ-TINT TOOL.

DISCLAIMER: XPEL IS NOT LIABLE FOR DAMAGE CAUSED BY IMPROPER USE OF EZ-TINT. USE OF EZ-TINT WITHOUT XPEL STEALTH INSTALLED IS NOT RECOMMENDED.

INSTRUCTIONS D'INSTALLATION DE PELLICULE PARE PIERRE STEALTH:

1. Arrosez la partie « insertion » de l'outil avec votre solution
2. Enveloppez la pellicule xpel stealth sur la partie de l'outil qui est insérée entre la moulure et la vitre.



3. Soutirez l'eau et les bulles et permettez un assèchement complet avant l'utilisation.

VEUILLEZ APPLIQUER LA PELLICULE AVANT L'UTILISATION.

AVERTISSEMENT: XPEL N'EST AUCUNEMENT RESPONSABLE DES DOMMAGES CAUSÉS PAR LE EZ-TINT DUE A UNE UTILISATION INADÉQUATE. L'USAGE DU EZ-TINT SANS LA PELLICULE PARE-PIERRE EST FORTEMENT DÉCONSEILLÉ.



M1900